

24G Human Presence Radar
R24AVD2-V
User Manual (V1.1)

Table of Contents

1. Introduction	2
2. Function description	2
2.1 Description of standard function point	2
3. Protocol description	3
4. Definition of communication command and parameter - standard function point/open underlying function point	3
4.1 Definition and description of frame structure	3
4.1.1 Definition of frame structure	3
4.1.2 Description of frame structure	4
4.2 Description of address assignment and data information	4
4.2.1 Description of standard function point	4
5. Disclaimer	12
6. Copyright notice	13
7. Contact	13
8. Updates history	13

Notes:

Click on the link or scan the QR code to make sure you're using the latest document:

http://en.micradar.cn/go_file.php?id=209

1. Introduction

This document mainly describes the use of radar, the problems that may be encountered at different stages, to minimize the design costs and increase the stability of the product, and to improve the efficiency of the project.

Hardware circuit reference design, radar antenna and housing layout requirements, how to distinguish between interference and multi-functional UART protocol output.

The radar is a self-contained space sensing sensor, which is composed of RF antenna, radar chip and high-speed main frequency MCU. It relies on stable and flexible algorithm architecture core to provide solution for scene detections. It's equipped with upper computer or host computer to output detection status and data, and meet several groups of GPIO for user customization and development.

2. Function description

2.1 Description of standard function point

Function point for radar setting	State change time/function explanation
DP1: Presence/Non-presence	Report within 0.5s from non-presence to presence Output non-presence state in 30s from presence to non-presence
DP2: Active/static/non-presence	Report within 0.5s from static to active Report within 2s from active to static Report non-presence state when no one is present
DP3: Approaching/Leaving Away/None	Report within 0.5s; if someone is approaching/leaving away from the device, report the approaching/leaving-away state
DP4: Body motion amplitude parameter 0-100	Output data every 1 second Reference (Description of body motion amplitude parameter output)

DP5: Maximum distance setting for presence sensing boundary	The radar breathing detection distance is set to reduce the radar's false alarm rate. Reduce interference outside the detection range [Range: 0.5-4m]
DP6: Maximum distance setting for motion triggering boundary	The human motion detection distance is set to reduce the radar's false alarm rate. Reduce interference from walking near the doors and glass doors beyond the detection range. [Range: 0.5-4m]
DP7: Motion distance value reporting	Motion distance: The module detects the linear distance of human motion; [Range: 0-4m],

3. Protocol description

This protocol is applied to the communication between the 24G millimeter wave human presence detection radar and the host computer.

This protocol outlines the radar workflow, gives a brief introduction to the interface protocol composition architecture, and explains the control commands and data required for radar operation. The serial communication is defined as follows:

- Interface level: TTL
- Baud rate: 115200bps
- Stop bit: 1
- Data bit: 8
- Parity check: No

4. Definition of communication command and parameter - standard function point/open underlying function point

4.1 Definition and description of frame structure

4.1.1 Definition of frame structure

Frame header	Control word	Command word	Length identification		Data	Check digit	Frame tail
0X53 0X59	Control	Command	Lenth_H	Lenth_H	Data	Sum	0X54 0X43
2 Byte	1 Byte	1 Byte	1 Byte	1 Byte	n Byte	1 Byte	2 Byte

4.1.2 Description of frame structure

➤ Frame header: 2Byte, fixed to 0X53,0X59;

➤ Control word: 1 Byte

(0x01-heartbeat packet identification, 0x02-product information, 0x03-OTA upgrade, 0x05-working status, 0x80-human presence)

➤ Command word: 1Byte (identification of current data)

➤ Length identification: 2Byte, equal to the specific byte length of data

➤ Data: nByte, defined according to the actual function

➤ Check digit: 1 Byte (check digit calculation: (frame header + control word + command word + length identifier + data) take the lowest eight bits after summation)

➤ Frame end: 2Byte, fixed to 0X54,0X43;

4.2 Description of address assignment and data information

4.2.1 Description of standard function point

Category	Function description	Transmission direction	Frame header	Control word	Command word	Length identification	Data	Check field	Frame tail	Remarks
System functions	Heartbeat packet report	Report	5359	01	01	0001	0F	sum	5443	
	Heartbeat package query	Issue	5359	01	80	0001	0F	sum	5443	
		Reply	5359	01	80	0001	0F	sum	5443	
	Module reset	Issue	5359	01	02	0001	0F	sum	5443	
		Report	5359	01	02	0001	0F	sum	5443	
	Proactive	Issue	5359	01	03	0001	00:	sum	5443	

	reporting switch						Disable 01: Enable			
		Report	5359	01	03	0001	00: Disable 01: Enable	sum	5443	
	Proactive reporting switch query	Issue	5359	01	83	0001	0F	sum	5443	
		Report	5359	01	83	0001	00: Disable 01: Enable	sum	5443	
Information query										
Product Info	Product model query	Issue	5359	02	A1	0001	0F	sum	5443	
		Reply	5359	02	A1	len	len B product information	sum	5443	
	Product id query	Issue	5359	02	A2	0001	0F	sum	5443	
		Reply	5359	02	A2	len	len B product id	sum	5443	
	Hardware model query	Issue	5359	02	A3	0001	0F	sum	5443	
		Reply	5359	02	A3	len	len B hardware model	sum	5443	
	Firmware version query	Issue	5359	02	A4	0001	0F	sum	5443	
		Reply	5359	02	A4	len	len B firmware version query	sum	5443	
Work ing status	Function point reporting									
	Message of initialization	Report	5359	05	01	0001	00: Initializati on failed; 01:	sum	5443	

	complete						Initializati on finished			
	Information query									
	Initializati on completi on informatio n query	Issue	5359	05	81	0001	0F	sum	5443	
		Reply	5359	05	81	0001	01: Completed 02: Not completed	sum	5443	
Human presence function	Human presence report and function point setting									
	Human presence informatio n report	Report	5359	80	01	0001	00: Non-prese nce 01: Presence	sum	5443	Report method: Report on status changes
	Movement informatio n report	Report	5359	80	02	0001	00: No 01: Static 02: Active	sum	5443	Report method: Report on status changes
	Body movement parameter report	Report	5359	80	03	0001	1B body movement parameters	sum	5443	Report method: Report every 1s Value range: 0-100
	Non-prese nce time settings	Issue	5359	80	04	0002	2B Access non-presen ce time: 30s-65535 s	sum	5443	30s by default, ranging from 10s to 1800s
		Reply	5359	80	04	0002	2B Access non-presen ce time: 30s-65535 s	sum	5443	

	Maximum distance setting for presence sensing boundary	Issue	5359	80	06	0001	1B distance setting	sum	5443	Ranging from 1 to 4 (distance setting interval of 1), Unit: m
		Reply	5359	80	06	0001	1B distance setting	sum	5443	
	Manual learning environment setting	Issue	5359	80	07	0001	01: Learning 00: None-learning	sum	5443	
		Reply	5359	80	07	0001	01: Learning 00: None-learning	sum	5443	
	Learning environment time interval setting	Issue	5359	80	08	0002	2B time setting	sum	5443	Value range: 10-3600 Unit: s
		Reply	5359	80	08	0002	2B time setting	sum	5443	
	Static background noise reporting	Issue	5359	80	0A	0014	20 bytes of background noise data	sum	5443	0-65535
	Static background noise threshold setting	Issue	5359	80	0B	0014	20 bytes of background noise data	sum	5443	Range: 0-65535 Each 2 bytes represents a distance segment (1 m)
		Reply	5359	80	0B	0014	20 bytes of background noise data	sum	5443	
	Real-time static threshold	Issue	5359	80	13	0001	00: Disable 01: Enable	sum	5443	

	reporting switch	Reply	5359	80	13	0001	00: Disable 01: Enable	sum	5443	
	Information query									
	Presence information query	Issue	5359	80	81	0001	0F	sum	5443	
		Reply	5359	80	81	0001	00: Non-presence 01: Presence	sum	5443	
	Movement information query	Issue	5359	80	82	0001	0F	sum	5443	
		Reply	5359	80	82	0001	00: No 01: Static 02: Active	sum	5443	
	Body movement parameter query	Issue	5359	80	83	0001	0F	sum	5443	Value range: 0-100
		Reply	5359	80	83	0001	1B body movement parameters	sum	5443	
	Access non-presence time query	Issue	5359	80	84	0001	0F	sum	5443	Value range: 10-1800s
		Reply	5359	80	84	0001	2B Access non-presence time	sum	5443	
	Maximum distance query for presence sensing boundary	Issue	5359	80	86	0001	0F	sum	5443	Ranging from 1 to 4 (distance setting interval of 1), Unit: m
		Reply	5359	80	86	0001	1B distance setting	sum	5443	
	Manual learning	Issue	5359	80	87	0001	0F	sum	5443	

	environment setting query	Reply	5359	80	87	0001	01: Learning 00: None-learning	sum	5443	
	Learning environment time interval setting query	Issue	5359	80	88	0001	0F	sum	5443	Value range: 10-3600 Unit: s
		Reply	5359	80	88	0002	2B time setting	sum	5443	
	Static background noise threshold query	Issue	5359	80	8B	0001	0F	sum	5443	
		Reply	5359	80	8B	0014	20 bytes of background noise data	sum	5443	0-65535
	Real-time static threshold reporting switch query	Issue	5359	80	93	0001	0F	sum	5443	
		Reply	5359	80	93	0001	00: Disable 01: Enable	sum	5443	
	Motion triggering function	Approach/ Stay Away	Report	5359	82	0A	00: No 01: Leaving away 02: Approaching	sum	5443	
		Maximum distance setting for motion triggering boundary	Issue	5359	82	0C	1B distance setting	sum	5443	Ranging from 1 to 4 (distance setting interval of 1), Unit: m
			Reply	5359	82	0C	1B distance setting	sum	5443	

	Dynamic background noise reporting	Report	5359	82	10	0014	20 bytes of background noise data	sum	5443	0-65535
	Dynamic background noise threshold setting	Issue	5359	82	11	0014	20 bytes of background noise data	sum	5443	Range: 0-65535 Each 2 bytes represents a distance segment (1 m)
		Reply	5359	82	11	0014	20 bytes of background noise data	sum	5443	
	Real-time motion threshold reporting switch	Issue	5359	82	15	0001	00: Disable 01: Enable	sum	5443	
		Reply	5359	82	15	0001	00: Disable 01: Enable	sum	5443	
	Motion distance value reporting	Report	5359	83	16	0001	1B distance value	sum	5443	Unit: dm
Information query										
	Approaching/Leaving-away query	Issue	5359	82	8A	0001	0F	sum	5443	
		Reply	5359	82	8A	0001	00: No 01: Leaving away 02: Approaching	sum	5443	
	Maximum distance query for motion	Issue	5359	82	8C	0001	0F	sum	5443	Ranging from 1 to 4 (distance setting interval)
		Reply	5359	82	8C	0001	1B distance	sum	5443	

	triggering boundary						setting			of 1), Unit: m
	Dynamic threshold query	Issue	5359	82	91	0001	0F	sum	5443	
		Reply	5359	82	91	0014	20 bytes of background noise data	sum	5443	0-65535
	Real-time motion threshold reporting switch query	Issue	5359	82	95	0001	0F	sum	5443	
		Reply	5359	82	95	0001	00: Disable 01: Enable	sum	5443	
	Motion distance value query	Issue	5359	82	96	0001	0F	sum	5443	
		Reply	5359	82	96	0001	1B distance value	sum	5443	Unit: dm
	OTA function									
OTA function	Start OTA upgrade	Issue	5359	03	01	0004	4B upgrade packet size	sum	5443	
		Reply	5359	03	01	0004	4B firmware size per frame	sum	5443	
	Upgrade package transmission	Issue	5359	03	02	Len+4	4Byte packet offset address + len B upgrade packet	sum	5443	
		Reply	5359	03	02	0001	01: Received 02: Failed	sum	5443	

							to receive			
	Stop OTA upgrade	Issue	5359	03	03	0001	01: Upgrade package transmission completed 02: Upgrade package transmission uncompleted	sum	5443	
		Reply	5359	03	03	0x0001	0F	sum	5443	

Appendix 1: Example of data instruction generation

Example: Presence information query:

The data structure for confirming the presence information query according to the protocol form above:

- Frame header: 0X53 0X59
- Control word: 0X80
- Command word: 0X81
- Length identification: 0X00 0X01
- Data: 0X0F
- Check digit: 1 Byte (SUM)
- Frame end: 0X54 0X43
- Combined to a complete command as: 53 59 80 81 00 01 0F sum 54 43
- Check digit sum: $(0X53+0X59+0X80+0X81+0X00+0X01+0X0F) = 0X01BD$
Take the lower byte to get sum = 0XBD

So the complete presence information query command is: 53 59 80 81 00 01 0F BD 54 43

5. Disclaimer

To our best knowledge, the description in the document is accurate when it was released.

Considering the technical complexity of products and the differences in working environments, it's impracticable to eliminate each and every inaccurate or imperfect description. On this account, this document is for reference by the user only. We reserve the right to make any changes to the product without a prior notice to the user. We make no commitments nor guarantees on the legal level. We encourage the customers to give valuable opinions on the latest update on the product and its supportive tools.

6. Copyright notice

All elements and parts mentioned herein constitute a reference to publications disclosed by the corresponding copyright holders, who shall reserve the rights to modify and publish the same. Please confirm the updates and corrigenda of such information via appropriate channels prior to any use of them. We hold no rights and obligations as for these publications.

7. Contact

Yunfan Ruida Technology (Shenzhen) Co., Ltd.

Email: sales@micradar.cn.

Telephone: 0755-88602663

Address: 501, West Block, Tian'an Innovation Technology Plaza (Phase 2), Futian District, Shenzhen, Guangdong Province

8. Updates history

Revision	Release Date	Summary
V1.0	2024/11/04	first draft
V1.1	2025/02/27	Instructions for optimizing learning environment time and optimizing unattended time